

Notice:

Seiko Japanese quality movements are used in your watch, we have a battery saver plastic strip this disables the battery as the crown is pulled out which in turn disables the arms which will be loose on the watch, once the battery saver strip is removed the watch can be set up with the correct time, please see the operation as below:




DIAGRAM 1




DIAGRAM 2

INSTRUCTION SHEET

A PLASTIC BATTERY STOPPER HAS BEEN INSERTED ON THE CROWN AS SHOWN IN DIAGRAM 1

REMOVE THE BATTERY STOPPER AND TWIST THE DRIVING CROWN TO ADJUST THE TIME,
AFTER TIME ADJUSTING FINISHED,PUSH THE CROWN BACK INTO THE PLACE FOR THE
WATCH TO START AS SHOWN IN DIAGRAM 2